

Fire detection and evacuation solutions that save lives.





Features

- Certified to AS 7240-5, 7, 11, 25 and NZS 4512:2010
- Analogue Addressable System Expansion
- Wireless
- Eliminates Cabling Difficulties.
- Minimises Disruptions.
- Enables Rapid Retrofit.
- Preserves Aesthetics.

A **Halma** company



Fire detection and evacuation solutions that save lives.



XPÅNDER

Xpander is a system in which individual detectors, call points, interfaces and alarm devices communicate with the analogue addressable loop by radio signals.

A loop-powered Xpander interface controls up to 31 Xpander wireless devices. Each Xpander device is assigned a loop address with the exception of the combined devices, which occupy 2 addresses (31 combined devices use 62 addresses on the control panel). Each address is recognised by the control panel in the same way as other addressable devices connected

directly to the detection loop wiring.

Multiple Xpander interfaces can be installed on each site.

Xpander can be incorporated into fire detection systems in stately homes and architecturally sensitive buildings where the use of fire cables is either impractical or undesirable.

All of the products within the Xpander range are approved to AS 7240-25 and NZS 4512 which is the industry standard for radio equipment used in fire safety areas.

- Easy to install
- Compatible with LoopSense & FireFinder Plus
- XPERT card addressing
- Self-monitoring
- Proven technology
- 915MHz radio channels
- Up to 31 devices per interface
- Up to 5 interfaces per loop



XPander Optical Smoke Detector & Mounting Base 4106-5303



XPander Heat Detector & Mounting Base 4106-5301 (A1R) 4106-5302 (CS)



XPander Multisensor Smoke Detector & Mounting Base

4106-5304



XPander Combined Sounder & Detector

4111-1303 (Optical) 4111-1301 (A1R) 4111-1302 (CS) 4111-1304 (Multi)



XPander Combined Sounder Visual Indicator & Detector Red

Visual Indicator

4111-1401 (A1R) 4111-1402 (CS) 4111-1403 (Optical) 4111-1404 (Multi)



XPander Combined Sounder Visual Indicator & Detector

4111-1503 (Optical) 4111-1504 (Multi)



XPander Manual Call Point 4105-5001



XPander Sounder with Mounting Base 4107-8301 (Red)

4107-8302 (White)



XPander Sounder Visual Indicator with Mounting Base

4107-8303 (Red) 4107-8304 (Clear/White Base) 4107-8305 (Amber/White Base)



CS Heat Detector

4106-5203

4106-5202

Optical Detector

4106-5204

Multisensor Detector

4106-5100 Detector Base

4111-1100 Sounder Detector Base

4111-1101

Sounder Beacon Detector Base

4107-8101

Sounder Base Red

4107-8201

4107-8203

Sounder Beacon Red





XPander Diversity Interface 4110-2001



XPander Hub & Cluster 4110-2004 (Radio Hub) 4110-2005 (Comms Cluster)



XPander Diversity Survey Kit 4112-1001

